Filter Replacement (item # LF-2-R) for Luxe Flow (model # LF-2) and those Common Questions

HOW OFTEN SHOULD I REPLACE MY FILTER?

Annually, or up to one year based on local water conditions and usage. You should not exceed a year. Sometimes the filter may clog or have a slower flow rate based on what the filter is capturing and therefore based on your water conditions the filter may have to be replaced more frequently.

HERE IS A NOTE ABOUT THE FILTER LIFE.

Filter is high capacity 10,000 gallon filter and under normal circumatances should last up to one year before replacement is needed*.

*Filter service life is based on local water conditions and your usage and should be replaced annually or as needed and not to exceed one year. Fine sediment, micro-plastics or certain water conditions may prematurely reduce flow rate and service life due to the filters' ability to capture and absorb contaminates. Replace as needed.

JUST INSTALLED MY FILTER AND MY WATER IS CLOUDY?

If you draw your water into a glass and it appears to be cloudy, it's only air and nothing bad. Let the glass sit and watch the air rise and dissipate. The filter cartridge used is full bed depth. The carbon (GAC) block cartridge has a great deal of surface area. With usage, it may take 24-48 hours for this to correct itself.

WHAT DO I DO IF THE FILTER IS CONNECTED TO OTHER DEVICES?

If water is being used for ice-maker, refrigerator water dispenser, hot tank or chiller, then run water through these devices to flush unit and discard this water or ice before consuming. Even though there is no harm from the carbon and the materials used are strictly organic, the fines or dust as a result may be an aesthetic issue.

WHAT IS THE ITEM # I NEED TO ORDER?

The correct item # is LF-2-R (E1101)

WHERE DO I GET MY FILTER REPLACEMENT?

GO TO WWW.LOCKESUPPLY.COM TO FIND A LOCATION NEAR YOU.

FOR ALL OTHER INFORMATION ON YOUR LUXE FLOW SYSTEM PLEASE SEE THE SERVICE MANUAL THAT WAS INCLUDED WITH YOUR SYSTEM

INSTRUCTIONS FOR FILTER REPLACEMENT





LUXEFLOWFiltered water at the speed of your faucet.

- · American-made quality and performance.
- · Highest quality carbon block filtration available.
- Meets or exceeds all compliances.
- Hassle-free and low maintenance.
- · Quick and easy installation no tools required.
- Comes complete with everything you need.
- No separate dispenser needed.
- · No drilling any holes in your sink or countertop.

Chlorine and its byproducts are known carcinogens. Drinking them is not recommended.* The New York State Deptartment of Health and President's Cancer Panel recommend water filtration to reduce or eliminate our exposure to these substances.

REMOVES CHLORAMINE, CHLORINE, THMS, VOCS, PESTICIDES, LEAD. CYSTS. RUST. DIRT. SEDIMENT. & MORE.¹

High capacity, high flow, in-line filter that installs directly to your faucet.

FILTER REPLACEMENT ITEM NUMBER:

LF - 2 - R (E1101)

GO TO WWW.LOCKESUPPLY.COM TO FIND A LOCATION NEAR YOU.

How to Replace Your Filter

Step 1 Close inlet water supply shut-off valve to the system.

Step 2 Open cold side of your faucet (and if applicable, allow other device(s) to flow).

Allow water to flow. Water should stop in a short time.

Keep open to relieve pressure.

WATER WILL BE PRESENT WHEN FILTER IS CHANGED. CAUTION:

A pan, towel, etc. should be placed under the system to catch

any water.

Step 3 Unlock from the head by turning filter to the left and remove old

filter cartridge.

Step 4 CONNECT THE FILTER CARTRIDGE TO THE FILTER HEAD:

4 a. Using plain water only, moisten the 2 small O-Rings at the top of the filter cartridge.

Keep clean. Remove any debris

Hold filter head firmly with one hand. 4 b.

4 c. Align filter cartridge into the head. Luxury Line - Luxe Flow label will be to your left.

- Insert filter cartridge and push upwards. 4 d.
- Turn to right until filter cartridge stops. 4 e. See direction of lock \rightarrow on the label.

Filter cartridge is now locked and the Luxury Line - Luxe Flow label is front and center.

Correct Start-Up and Set Reminder for Filter Replacement

A proper start-up insures the unit is without issues. If anything is discovered, this is the time to discover it and correct any problems or questions that arise.

Step 5 START UP:

5 a. Your faucet should still be open from Step # 1.

If not, open your faucet to the cold side only.

No water should be present at this time.

5 b. Slowly and completely open shut-off valve under the sink to get water to the system - open slowly.

> Water will begin to flow from faucet. Initially it may sputter until water reaches full flow.

NOTE: Check connections for any leaks. If a leak is observed, close shut-off valve and water to the system. Common and easy to correct. Remove filter, moisten the o-rings and re-insert as instructed from Step # 4.

FLUSH: 5 C.

Picture for

illustration

purposes only.

Luxe Flow

filter head has been

modified

Allow unit to run steadily for 3 minutes. This will wash carbon fines and air from the filter and properly pressurize the system.

5 d. **ENJOY**

Observe that the water runs clear. System is now available to use as normal. Use for all your drinking, cooking, coffee, etc.

SET A REMINDER: Step 6

Set the one year anniversary of this installation into your smart phone or calendar to remind you to replace the filter.

GO TO PROPER START-UP OF THE SYSTEM