



LEW ELECTRIC FITTINGS COMPANY

OPERATING INSTRUCTIONS FOR PUFP-CT SERIES BOXES

Note: *The Lew Electric PUFP-CT series boxes have an adjustable tension mechanism that adjusts the speed at which the lid “pops” open. This should be adjusted during installation according to end user preference.*

1. To open cover and expose receptacle, press and **hold** the PUSH button until the lid has reached its maximum height. Failure to hold the PUSH button will cause the metal latch to slide back into the locked position prematurely causing the lid to cease opening before it is in the full open position.

Note: *If the metal latch does not slide back into the locked position when the lid is in the full open position, and the PUSH button has been released, the tension screw needs to be adjusted to increase the tension and speed in which the lid “pops” open.*

2. To close lid and hide receptacle, press and hold the PUSH button while pushing the top of the lid closed with opposite hand. With lid firmly closed and held, release the push button. Finally release the lid.

Note: If lid is released before the metal latch has secured the lid in the closed position, the lid will pop back open. This is not a defect in the product. It is user error.

If further instruction is needed, please visit www.lewelectric.com and view the installation video under the residential tab.

ATTENTION INSTALLERS: PLEASE LEAVE THESE OPERATING INSTRUCTIONS FOR THE END USER.